




1. Disconnect the flapper from the flush valve.




2.Position flush valve into the mounting hole.




3. Tighten the bolt onto the "U" shaped hook by screw driver, make sure the flush valve is fixed properly.



4.Connect the flapper to flush valve.



5.On the basis of form a complete set of lever installation instructions, install the tank lever in the toilet water tank corresponding assem bly position.



6.Connect the flapper chain. Allow slight slack when flapper is in closed position.